

MANUAL GEARBOX

CONTENTS

Description and Operation	Page
Gearbox components - PG1 gearbox	3
Gearbox components - PG2 gearbox	5
Cutaway view of gearbox - PG1 gearbox	5
Cutaway view of gearbox - PG2 gearbox	6
Gear linkage components - PG2 unit illustrated	9
Cross section of gearbox - PG2 illustrated	10
Operation	11

Adjustments	Page
Gearbox - drain and refill	1
Mainshaft end thrust - PG1 gearbox	2
Mainshaft end thrust - PG2 gearbox	5
Differential bearing pre-load - PG2 gearbox	7

Repairs	Page
Speedometer pinion - PG1 gearbox - renew	1
Differential oil seal - renew	2
Gear lever renew	3
Gear linkage and bushes - renew	4
Gearbox - PG1 - renew	5
Gearbox - PG2 - renew	7
Gearbox case - renew	10
Selector mechanism - renew	12
Mainshaft - renew	16
Countershaft - renew	20
Differential - PG1 gearbox - overhaul	24
Differential - PG2 gearbox - overhaul	26
Neutral and reverse light switches - renew	28

▲ CAUTION: Care must be taken when overhauling PG1 gearboxes. Two suppliers are used and many components are not interchangeable. Repair procedures that differ are identified as follows:

PG1¹ - gearboxes up to No. 1999999

PG1² - gearboxes from 2000001



NOTES

Symbols have the following meanings:

→ = TO

← = FROM

▲ = WARNING

▲ = CAUTION

▲ = NOTE

⊞ = TORQUE WRENCH FIGURE

⊞ = SERVICE TOOL

⊞ = FASTCHECK TOOL


⊞ = NON REUSABLE ITEM

⊞ = INFORMATION



MANUAL GEARBOX

DESCRIPTION AND OPERATION



XM0210

MANUAL GEARBOX

DESCRIPTION AND OPERATION




GEARBOX COMPONENTS - PG1 GEARBOX

1. Oil seal - differential
2. Differential housing
3. Speed sensor - instruments
4. Dowel
5. Oil seal - selector rod
6. Boot
7. Selector rod
8. Thrust washer - sun gear
9. Sun gear
10. Thrust washer - planet pinion
11. Planet pinion
12. Pinion shaft
13. Ball bearing - differential
14. Final drive gear
15. Roll pin - differential pinion shaft
16. Differential casing
17. Ball bearing - differential
18. Selective shim
19. Clutch release arm
20. Oil seal - clutch release arm
21. Selector rod guide
22. Dowel bolt and washer
23. Magnet
24. Detent cap bolt, ball and spring - selector rod
25. Oil guide plate
26. Parallel roller bearing - countershaft
27. Countershaft
28. Selective thrust washer - 1st gear end float
29. Needle roller bearing - 1st gear
30. 1st gear
31. Synchro ring - 1st gear
32. Synchro spring
33. Synchro hub - 1st/2nd gear
34. Synchro sleeve - 1st/2nd gear
35. Synchro spring
36. Synchro ring - 2nd gear
37. Selective collar - 2nd gear end float
38. Needle roller bearing - 2nd gear
39. 2nd gear
40. 3rd gear
41. 4th gear
42. 5th gear
43. Roller bearing - countershaft
44. Ball bearing - countershaft
45. Washer
46. Countershaft nut - L.H. thread
47. Circlip
48. Reverse idler shaft
49. Thrust washer - reverse idler gear
50. Roll pin - reverse idler shaft
51. Reverse idler gear
52. Reverse fork
53. Oil seal - mainshaft
54. Ball bearing - mainshaft
55. Mainshaft
56. Needle roller bearing - 3rd gear
57. 3rd gear
58. Synchro ring - 3rd gear
59. Synchro spring
60. Synchro hub - 3rd/4th gears
61. Synchro sleeve - 3rd/4th gears
62. Synchro spring
63. Synchro ring - 4th gear
64. 4th gear
65. Needle roller bearing - 4th gear
66. Distance collar - 4th/5th gears
67. Needle bearing - 5th gear
68. 5th gear
69. Synchro ring
70. Synchro spring
71. Synchro hub - 5th gear
72. Synchro sleeve - 5th gear
73. Ball bearing - mainshaft
74. Selective snap rings - mainshaft end thrust
75. Belleville washer - mainshaft end thrust
76. Oil guide plate
77. Gearbox casing
78. Reverse idler shaft bolt and washer
79. Breather pipe
80. Breather pipe bracket
81. Oil seal - differential
82. Filler/level plug
83. Drain plug
84. Access plug - countershaft bearing circlip
85. Reverse light switch
86. Shift arm assembly
87. Interlock
88. Shift arm guide
89. Shift shaft
90. Roll pin - 5th/reverse gear selector
91. Gear selector - 5th/reverse gears
92. Selector fork - 3rd/4th gears
93. Selector fork - 5th gear
94. Selector shaft - 5th/reverse gears
95. Selector fork - 1st/2nd gears
96. Selector shaft - 1st/2nd gears



MANUAL GEARBOX

DESCRIPTION AND OPERATION



XM0211 A

MANUAL GEARBOX

DESCRIPTION AND OPERATION




GEARBOX COMPONENTS - PG2 GEARBOX

1. Oil seal - differential
2. Differential housing
3. Speed sensor - instruments and power steering
4. Dowel
5. Oil seal - selector rod
6. Boot
7. Selector rod
8. Thrust washer - sun gear
9. Sun gear
10. Thrust washer - planet pinion
11. Planet pinion
12. Pinion shaft
13. Taper roller bearing - differential
14. Final drive gear
15. Roll pin - differential pinion shaft
16. Differential casing
17. Taper roller bearing - differential
18. Selective shim - differential pre-load
19. Boot
20. Clutch release arm and damper
21. Pivot - clutch release arm
22. Selector rod guide
23. Dowel bolt and washer
24. Magnet
25. Detent cap bolt, ball and spring - selector rod
26. Retainer plate - countershaft bearing
27. Oil guide plate
28. Parallel roller bearing - countershaft
29. Countershaft
30. Selective thrust washer - 1st gear end float
31. Needle roller bearing - 1st gear
32. 1st gear
33. Synchro ring - 1st gear
34. Synchro spring
35. Synchro hub - 1st/2nd gear
36. Synchro sleeve - 1st/2nd gear
37. Synchro spring
38. Synchro ring - 2nd gear
39. Selective collar - 2nd gear end float
40. Needle roller bearing - 2nd gear
41. 2nd gear
42. 3rd gear
43. 4th gear
44. 5th gear
45. Roller bearing - countershaft
46. Ball bearing - countershaft
47. Washer
48. Countershaft nut - L.H. thread
49. Circlip
50. Reverse idler shaft
51. Thrust washer - reverse idler gear
52. Roll pin - reverse idler shaft
53. Reverse idler gear
54. Reverse fork
55. Oil seal - mainshaft
56. Belleville washer - mainshaft end thrust
57. Ball bearing - mainshaft
58. Mainshaft
59. Needle roller bearing - 3rd gear
60. 3rd gear
61. Synchro ring - 3rd gear
62. Synchro spring
63. Synchro hub - 3rd/4th gears
64. Synchro sleeve - 3rd/4th gears
65. Synchro spring
66. Synchro ring - 4th gear
67. 4th gear
68. Needle bearing - 4th gear
69. Distance collar - 4th/5th gears
70. Needle bearing - 5th gear
71. 5th gear
72. Synchro ring
73. Synchro spring
74. Synchro hub - 5th gear
75. Synchro sleeve - 5th gear
76. Ball bearing - mainshaft
77. Selective snap rings - mainshaft end thrust
78. Oil guide plate
79. Gearbox casing
80. Lifting eye
81. Reverse idler shaft bolt and washer
82. Breather pipe
83. Breather pipe bracket
84. Reverse light switch harness bracket
85. Oil seal - differential
86. Filler/level plug
87. Drain plug
88. Access plug - countershaft bearing circlip
89. Reverse light switch
90. Shift arm assembly
91. Interlock
92. Shift arm guide
93. Shift shaft
94. Roll pin - 5th/reverse gear selector
95. Gear selector - 5th/reverse gears
96. Selector fork - 3rd/4th gears
97. Selector fork - 5th gear
98. Selector shaft - 5th/reverse gears
99. Selector fork - 1st/2nd gears
100. Selector shaft - 1st/2nd gears



MANUAL GEARBOX

DESCRIPTION AND OPERATION




CUTAWAY VIEW OF GEARBOX - PG1 GEARBOX

- | | |
|------------------------------|---|
| 1. Oil guide plate | 8. Access plug - countershaft bearing circlip |
| 2. Mainshaft assembly | 9. Countershaft assembly |
| 3. Gearbox case | 10. Shift arm assembly and interlock |
| 4. Reverse idler shaft bolt | 11. Selective shims |
| 5. Reverse idler gear | 12. Differential assembly |
| 6. Breather pipe and bracket | 13. Speed sensor - instruments |
| 7. Differential housing | 14. Selector rod |

MANUAL GEARBOX

DESCRIPTION AND OPERATION




CUTAWAY VIEW OF GEARBOX - PG2 GEARBOX

- | | |
|---|---|
| 1. Oil guide plate | 9. Countershaft assembly |
| 2. Mainshaft assembly | 10. Shift arm assembly and interlock |
| 3. Gearbox case | 11. Selective shims - differential pre-load |
| 4. Reverse idler shaft bolt | 12. Differential assembly |
| 5. Reverse idler gear | 13. Speed sensor - instruments and power steering |
| 6. Breather pipe and bracket | 14. Selector rod |
| 7. Differential housing | |
| 8. Access plug - countershaft bearing circlip | |



MANUAL GEARBOX

DESCRIPTION AND OPERATION



XM0230

MANUAL GEARBOX

DESCRIPTION AND OPERATION




GEAR LINKAGE COMPONENTS - PG2 UNIT ILLUSTRATED

- | | |
|---------------------|---------------------|
| 1. Gear lever knob | 12. Gear lever boot |
| 2. Gear lever | 13. Dust cover |
| 3. Sealing washer | 14. Retainer plate |
| 4. Bush | 15. Mounting rubber |
| 5. Spacer | 16. Collar |
| 6. O ring | 17. Bracket |
| 7. Circlip | 18. Washer |
| 8. Retaining ring | 19. Bush |
| 9. O ring | 20. Steady rod |
| 10. Gear lever seat | 21. Selector rod |
| 11. Dust cover | |



MANUAL GEARBOX

DESCRIPTION AND OPERATION



XM0212

CROSS SECTION OF GEARBOX - PG2 ILLUSTRATED



OPERATION

Two types of manual gearbox are fitted to the Rover 800 range, type PG1 which is fitted to 2.0 engine models and type PG2 which is fitted to V6 engine models. Both types are 5 speed constant mesh gearboxes employing helical tooth gears and are fitted transversely in the vehicle.

The gearbox comprises two housings, the differential housing and the gearbox casing. The gearbox casing houses the mainshaft and countershaft.

1st, 2nd and reverse gears are integral with the mainshaft which also carries 3rd, 4th and 5th gears running on caged needle roller bearings. Mainshaft end thrust is adjusted by selective shims and a Belville washer located behind the bearing in the gearbox casing on the PG1 type gearbox. On the PG2 type gearbox, the selective shims are still located behind the bearing in the gearbox casing but the Belville washer is located at the opposite end of the mainshaft between the bearing and the 1st gear.

The countershaft carries 1st and 2nd gears on caged needle roller bearings with 3rd, 4th and 5th gears on splines. Reverse gear is integral with the synchromesh sleeve for 1st and 2nd gear. The reverse idler runs on a caged needle roller bearing on the idler shaft with a thrust washer fitted below it.

When the driver selects a gear, movement of the gear lever is transmitted to the selector rod located transversely in the differential housing and connected to a guide. This guide engages with the shift arm and interlock assembly which imparts movement to the required selector fork. The interlock mechanism prevents direct engagement of reverse gear from the 5th speed position.

Drive train

Mainshaft 1st gear (9) is integral with the shaft, the 1st/2nd selector fork pushes the 1st/2nd synchro sleeve (14) along its splines towards the countershaft 1st gear (16), the synchro ring synchronises the speed of the countershaft and the gear and the sleeve engages the splines on 1st gear locking the gear to the countershaft. This provides the drive train from mainshaft to countershaft. The final drive pinion (18) is integral with the countershaft and transmits torque to the final drive gear (17).

The remaining forward gears are engaged in a similar manner to 1st. In 2nd gear, mainshaft 2nd gear (6) is integral with the shaft and synchro sleeve (14) locks 2nd gear (13) to the countershaft.

In 3rd gear, 3rd/4th synchro sleeve (4) locks the 3rd gear (5) to the mainshaft. Countershaft 3rd gear (12) is splined to the shaft.

In 4th gear, 3rd/4th synchro sleeve (4) locks the 4th gear (3) to the mainshaft. Countershaft 4th gear (11) is splined to the shaft.

In 5th gear, 5th synchro(1) locks 5th gear (2) to the mainshaft. Countershaft 5th gear (10) is splined to the shaft.

In reverse gear, mainshaft reverse gear (8) is integral with the shaft, countershaft reverse gear (15) is integral with 1st/2nd synchro sleeve (14) and so is splined to the countershaft. The reverse fork pushes the reverse idler into engagement with the gears on the mainshaft and countershaft.

Differential


Power from the gearbox is transmitted to the final drive gear (17) which is bolted to the differential casing (19). Incorporated in this casing are the planet pinions (20) and sun gears (21) which are in constant mesh and comprise the differential assembly.

The sun gears are splined to the drive shafts and, when the vehicle is moving in a straight line the resistance to movement of both sun gears is equal. The differential transmits the drive through the pinion pin (22), forcing the differential casing to rotate as an assembly leaving the planet pinions and sun gears stationary.

When the vehicle is cornering, the inner road wheel will slow down, increasing the resistance to movement of the inner sun gear this causes the planet pinions to rotate on their own axis which in turn increases the speed of the outer sun gear thus increasing the speed of the outer road wheel.

Lubrication

Lubrication is by splash. A trough located above the gear trains collects splashed oil which spills to the countershaft differential housing bearing and to the mainshaft gearbox casing bearing where, by means of oil guide plates, it is directed into drillings in the respective shafts to lubricate the needle bearings in the gears.



XM0206

GEARBOX – DRAIN AND REFILL

Action

Ref. Detail

Special Instructions

Drive	vehicle	
Position	drain tray	
Remove	1. filler/level plug ← gearbox	
"	2. drain plug ← gearbox	
Drain	oil ← gearbox	
Remove	3. washer ← drain plug	
Clean	drain plug	
Fit	new washer → drain plug	
"	drain plug → gearbox	
Inject	oil → filler/level hole	
Fit	filler/level plug → gearbox	

Until gearbox is warm


⚠ CAUTION: Gearbox oil can be very hot



 40 Nm

See **Information, lubricants**



Until oil runs from hole

 45 Nm



MANUAL GEARBOX

ADJUSTMENTS



XM0219A

MAINSHAFT END THRUST - PG1 GEARBOX


Action	Ref. Detail	Special Instructions
Fit	1. bearing → differential housing	Leave out oil seal
"	2. mainshaft → differential housing	
Secure	3. gearbox case → differential housing assembly	Use several evenly spaced bolts
Position	4. straight edge → differential housing clearance	Differential housing uppermost
"		
Measure		Between straight edge and centre of mainshaft A
Tap	mainshaft	Gently downwards fully into gearbox case
Measure	clearance	Between straight edge and centre of mainshaft again

MANUAL GEARBOX

ADJUSTMENTS








Subtract	first reading ← second reading	Call dimension X
Measure	belville washer thickness	Add 0.17 mm, 0.693 in for end thrust. Call dimension Y
Subtract	dimension Y ← dimension X •	Value obtained = snap ring thickness required
		Example:
		X = 2.5 mm
		Y = 0.97 mm

		1.53 mm
Select	5. snap rings	Snap ring thickness required = 1.53 mm
		One or at most two to achieve thickness in calculation or as close as possible
		
		End thrust must be 0.14 – 0.21 mm, 0.005 – 0.008 in
		Snap rings available:
		From 0.50 mm to 1.15 mm, 0.020 in to 0.045 in in steps of 0.05 mm, 0.002 in
Fit	6. oil guide plate → gearbox case	
"	7. belville washer → gearbox case	
"	selected snap rings → gearbox case	
Reassemble	components	
Fit	selector forks and interlock assembly	
"	gearbox case	
"	gearbox → vehicle	



MANUAL GEARBOX ADJUSTMENTS





MAINSHAFT END THRUST - PG2 GEARBOX

Action	Ref. Detail	Special Instructions
Fit Position Measure	1. mainshaft → gearbox case 2. straight edge → gearbox case clearance	A mainshaft to straight edge using depth gauge. Take measurement with straight edge in two other positions. ▲ Note: Subtract thickness of straight edge from readings
Calculate Remove Fit Position Measure	average of three readings differential ← differential housing 3. bearing → differential housing 4. straight edge → differential housing clearance	B inner race to straight edge using depth gauge. Take measurement with straight edge in two other positions. ▲ Note: Subtract thickness of straight edge from readings
Calculate Select	average of three readings snap rings	Calculation A - B - 0.98 mm = snap ring thickness required 0.98 mm = mid point of flex on belville washer Example: <div style="display: flex; justify-content: space-between;"> <div style="text-align: right;"> A = 5.01 B = 2.22 --- 2.79 </div> <div style="text-align: right;"> 2.79 0.98 --- 1.81 </div> </div> Snap ring thickness required = 1.81 mm Select one or at most two snap rings to achieve thickness in calculation or as close as possible ■ Snap rings available: From 0.50 mm to 1.15 mm, 0.020 to 0.045 in in steps of 0.05 mm, 0.002 in e.g. 0.85 + 0.95 mm = 1.80 mm
Fit " " " " " " Tap Fit Slide Fit	5. oil guide plate → gearbox case 6. snap rings → gearbox case 7. belville washer → mainshaft 8. bearing → mainshaft 9. mainshaft → differential housing 10. gearbox casing → differential housing bolts → differential housing end of mainshaft 11. adaptor plate → differential housing 12. collar → mainshaft 13. shaft holder → mainshaft	Dished face away from 1st gear ■ 45 Nm Gently using a soft hammer ■ 18G 191 - 6 Part of ■ 18G 1528 Part of ■ 18G 1528 Align three Allen screws with groove behind splines and tighten evenly ▲ CAUTION: Do not tighten Allen screws against splines
Position " Secure Zero	14. dial gauge → adaptor plate plunger → end of mainshaft dial gauge dial gauge	With slight pre - load

Continued....



MANUAL GEARBOX

ADJUSTMENTS

Turn

15. bolt

Clockwise and note the reading on the dial gauge

▲ CAUTION: Do not turn the bolt more than 60 ° once gauge pointer stops moving.
DO NOT overtighten bolt



Reading must be 0.14 - 0.21 mm,
0.0055 - 0.0088 in

OK, reassemble components

Outside limits, re - calculate snap ring thickness

Reassemble

components

Fit


selector forks and interlock assembly

"

gearbox case

"

gearbox → vehicle



DIFFERENTIAL BEARING PRE - LOAD - PG2 GEARBOX

Action	Ref. Detail	Special Instructions
Fit	1. shim → gearbox case	Use standard size 2.15 mm, 0.085 in as starting point for adjustment ▲ CAUTION: Do not use more than one shim
"	2. bearing outer track → case	Ensure track is square and there is no clearance between track, shim and case
"	bearing outer track → housing	
Position	3. differential → differential housing	
Fit	4. gearbox case → differential housing	Do not fit mainshaft and countershaft 10 off, 45 Nm
Tighten	bolts → differential housing	Several times to seat bearings
Rotate	differential	18G 1527, slot in adaptor fits over pinion pin
Position	5. adaptor → pinion pin	

Continued . . .



MANUAL GEARBOX

ADJUSTMENTS

Fit
Turn

6. torque gauge → adaptor
differential

1 MS 103

Using **1** MS 103, note torque required to turn differential on its bearings

2 Pre-load = 1.4 – 2.0 Nm

Reading OK reassemble gearbox

Reading below limit, select thicker shim

Each increase in shim size will increase

pre-load by 0.4 Nm e.g. If reading obtained

was 0.8 Nm below maximum pre-load, fit

shim two sizes above

2.15 mm e.g. 2.25 mm, 0.088 in

Reading above limit, select thinner shim

Each decrease in shim size will decrease

pre-load by 0.4 Nm e.g. If reading obtained

was 0.4 Nm above maximum pre-load, fit

shim one size below

2.15 mm e.g. 2.10 mm, 0.083 in

3 shims available

1.90 mm (0.075 in) – 2.47 mm (0.097 in)

In steps of 0.03 mm, 0.001 in

Fit
Reassemble

selected shim → gearbox case
components

Fit

mainshaft and countershaft

"


selector forks and interlock assembly

"

gearbox case

"

gearbox → vehicle



XM0207



SPEEDOMETER PINION - PG1 GEARBOX - RENEW

For information on speedometer pinion fitted to PG2 gearbox, see **Steering**


Action	Ref. Detail	Special Instructions
Disconnect	1. multiplug ← harness	
Slide	2. boot	Upwards to gain access to clip
Remove	3. clip ← transducer	
"	4. transducer ← drive housing	
"	5. bolt ← retainer plate	11 Nm
Collect	6. retainer plate ← drive housing	
Remove	7. drive housing ← gearbox	
"	8. O rings ← drive housing	
"	9. clip ← drive housing	
Withdraw	10. pinion ← drive housing	
Inspect	components	Renew if worn or damaged
Lubricate	components	Use gearbox oil
Reassemble	components	



MANUAL GEARBOX REPAIRS



XM0222 A



DIFFERENTIAL OIL SEAL - RENEW

Action

Drain
Release
Lever
Clean
Drift

Ref. Detail

oil ← gearbox
driveshaft ← gearbox
seal ← differential housing
seal location
1. new seal → differential housing

Special Instructions


See **Adjustments**
Appropriate side. See **Drive shafts**
☐

Ensure sealing lip faces inwards
Use ☐ 18G 134, 18G 134-12 on PG1 gearbox
Use ☐ 18G 1526 on PG2 gearbox

Reassemble
Fill

components
gearbox with oil

See **Adjustments**



XM0229

GEAR LEVER RENEW

Action

Ref. Detail

Special Instructions

Remove

centre console ← vehicle

See **Body**

Raise

vehicle

Use 4 post lift


Remove

heat shield ← front pipe

See **Manifolds & Exhaust**

"

1. bolt ← selector rod

Collect nut  22 Nm

Disconnect

2. selector rod ← gear lever

Remove

3. circlip ← gear lever

"

4. gear lever

2 off 

"

5. sealing washers ← gear lever

"

6. spacer assembly ← gear lever

"

7. bushes ← gear lever

Continued . . .



MANUAL GEARBOX

REPAIRS

Remove

"

"

"

"

Clean

Inspect

Reassemble

- 8. O rings ← spacer
- 9. retaining ring ← gear lever
- 10. seat ← gear lever
- 11. O rings ← seat
- 12. dust cover ← gear lever


components

components

components

4 off

Renew as necessary



XM0228

GEAR LINKAGE AND BUSHES - RENEW

Action

Ref. Detail

Raise

vehicle

Remove

heat shield ← vehicle

"

1. bolt ← selector rod

Disconnect

2. selector rod ← gear lever

Remove

3. bolts ← floor

"

4. bracket

"

5. mounting rubber ← steady rod

"

6. collars ← mounting rubber

"

7. bolt ← steady rod

Disconnect

8. steady rod ← gearbox

Remove

9. washers ← steady rod

"

10. bush ← steady rod

"

11. clip ← selector rod

Special Instructions

Use 4 post lift

See **Manifolds & Exhaust**

Collect nut 22 Nm

2 off 22 Nm


2 off



Remove
Disconnect
Clean
Inspect
Reassemble

12. roll pin ← selector rod
13. selector rod ← gearbox
components
components
components

Renew as necessary



GEARBOX - PG1 - RENEW

Action	Ref. Detail	Special Instructions
Remove	air cleaner	See Fuel 2.7
Raise	front of vehicle	⚠ WARNING: Support on safety stands
Remove	front wheels ← drive flanges	8 nuts 72 Nm
Drain	oil ← gearbox	Refit drain plug 40 Nm
Remove	clips ← bonnet struts	2 off
Release	bonnet ← struts	
Tie back	bonnet	
Remove	panel ← L.H. inner wing	2 self tapping screws
"	spark plug cover ← engine	2 bolts 6 Nm
Disconnect	leads ← spark plugs	4 off, move aside
Support	engine	Use 18G 1522, 600963 and lifting chains
Remove	starter motor	See Electrical
Move	crankshaft sensor bracket aside	
Disconnect	leads ← reverse light switch	
Disconnect	conector ← speed sensor	


Continued . . .



MANUAL GEARBOX

REPAIRS

Remove	1. bolts ← longitudinal beam	8 off 45 Nm
"	2. longitudinal beam	
"	3. bolts ← lower snubber bracket	3 off 45 Nm
"	4. lower snubber bracket ← gearbox	
"	5. R clip ← clevis pin	
"	6. clevis pin ← clutch release arm	2 off 22 Nm
"	7. bolts ← clutch slave cylinder	Aside
Move	8. clutch slave cylinder	
Remove	9. clip ← roll pin	
"	10. roll pin ← selector rod	
"	11. bolt ← steady rod	25 Nm, collect two washers
Disconnect	12. selector rod ← shaft	
"	13. steady rod ← gearbox	
Remove	14. bolt ← rear mounting	40 Nm
"	15. nut ← front mounting	
Raise	engine	To clear mounting bracket
Remove	16. bolts ← engine mounting bracket	2 off 40 Nm
Release	both driveshafts ← gearbox	See Drive Shafts
Remove	L.H. tie rod	See Front Suspension
Disconnect	earth lead ← gearbox	
Remove	17. bolt ← gearbox	75 Nm
"	18. bolt ← gearbox	45 Nm
"	19. bolt ← rear tie rod	75 Nm
Lower	engine	
Position	jack	To support gearbox
Release	gearbox ← dowels	
Lower	jack	
Manoeuvre	gearbox ← vehicle	From below
Clean	mating surfaces	Engine and gearbox
Reassemble	components	
Fill	gearbox with oil	See Adjustments
Road Test	vehicle	



XM0202

GEARBOX - PG2 - RENEW

Action	Ref. Detail
Remove	air cleaner
Raise	front of vehicle
Remove	L.H. front wheel ← drive flange
Drain	oil ← gearbox
Remove	panel ← L.H. inner wing
"	starter motor
"	1. bolts ← longitudinal beam
"	2. longitudinal beam
"	3. bolts ← lower snubber bracket
"	4. lower snubber bracket ← gearbox
"	cover ← engine
"	5. clip ← roll pin
"	6. roll pin ← selector rod
"	7. bolt ← steady rod
Disconnect	8. selector rod ← shaft
"	9. steady rod ← gearbox
Position	jack below engine

Special Instructions

See **Fuel**

⚠ WARNING: Support on safety stands

4 nuts 72 Nm

2 self tapping screws

See **Electrical**

8 off 45 Nm

3 off 45 Nm

Flywheel access cover, located below engine

25 Nm, collect two washers

Continued . . .







MANUAL GEARBOX

REPAIRS

Remove	10. bolts ← engine mounting bracket	2 off 40 Nm
"	11. bolts ← clutch slave cylinder	2 off 22 Nm
"	12. slave cylinder ← gearbox slave cylinder	Aside
Move		
Remove	13. bolts ← rear mounting	2 off 40 Nm
"	bolt ← gearbox	45 Nm, located above R.H. drive shaft joint
Release	L.H. driveshaft ← gearbox	See Drive Shafts
"	reverse light multiplug ← bracket	
Disconnect	multiplug ← reverse light switch	
Remove	14. bolt ← gearbox	2 off 75 Nm
"	15. bolt ← speed sensor	10 Nm
Move	16. speed sensor	Aside
Plug	pinion orifice	To prevent dirt ingress
Remove	17. bolt ← tie rod	75 Nm, collect special nut
"	18. bolts ← tie rod brackets	2 off 40 Nm
"	tie rod brackets ← gearbox	2 off
Disconnect	earth lead ← gearbox	
Release	earth lead and harness	
Remove	19. bolt ← gearbox	75 Nm
Position	jack	To support gearbox
Release	gearbox ← dowels	
"	R.H. driveshaft ← gearbox	See Drive Shafts
Lower	jack	
Manoeuvre	gearbox ← vehicle	From below
Clean	mating surfaces	Engine and gearbox
Reassemble	components	
Fill	gearbox with oil	See Adjustments
Road Test	vehicle	

MANUAL GEARBOX

REPAIRS



XM0213







Continued . . .



MANUAL GEARBOX REPAIRS

GEARBOX CASE - RENEW

Action	Ref. Detail	Special Instructions
Remove	gearbox ← vehicle	
"	1. reverse light switch ← gearbox case	⌚ 25 Nm
"	2. lifting eye ← gearbox case	Two bolts ⌚ 24 Nm PG2 gearbox only
"	3. access plug ← gearbox case	Use ⌚ 18G 1472 Apply thread sealer for reassembly, ⌚ 70 Nm
"	4. bolt ← gearbox case	Secures reverse idler shaft ⌚ 70 Nm
"	5. detent cap bolt ← gearbox case	⌚ 33 Nm, extract spring and ball PG2 gearbox only
"	6. bolts ← gearbox case	14 off ⌚ 45 Nm Note position of breather and reverse light brackets and note bolt lengths
Release	7. snap ring ← countershaft	Use circlip pliers
Tap	8. gearbox case upwards	Use soft hammer
Remove	gearbox case ← differential housing	
<i>Do not carry out further dismantling if component is removed for access only</i>		
Drift	9. seal ← gearbox case	⌚
Transfer	10. snap rings → new case	
"	belville washer → new case	PG1 gearbox only
"	11. oil guide plate → new case	
"	12. filler/level plug → new box case	⌚ 45 Nm
"	13. drain plug → new box case	⌚ 40 Nm
"	14. sealing plug → new case	⌚ 30 Nm
"	bearing outer track → new case	
"	shim → gearbox case	PG2 gearbox only
"	circlip → gearbox case	PG1 gearbox only
Clean	all components	
Inspect	components	Renew as necessary
Adjust	mainshaft end thrust	See Adjustments
"	differential bearing pre - load	PG2 gearbox, see Adjustments
Check	differential bearing end - float	PG1 gearbox
Apply	RTV sealant → differential housing face	Thin continuous bead ⚠ CAUTION: Allow 30 minutes for sealant to cure before filling with oil
Lubricate	seals	With gearbox oil
Fit	differential seal	Use ⌚ 18G 134, 18G 134 - 12 on PG1 gearbox Use ⌚ 18G 1526 on PG2 gearbox
Reassemble	components	
Renew	sealing washers	
Tighten	bolts → gearbox case	Sequence illustrated
Check	mainshaft end thrust	
Fit	gearbox → vehicle	PG2 gearbox only, see Adjustments



XM0214A

Continued . . .





MANUAL GEARBOX

REPAIRS

SELECTOR MECHANISM - RENEW

Action	Ref. Detail	Special Instructions
Remove	gearbox ← vehicle	
"	gearbox case	
"	1. bolts ← differential housing	2 off 15 Nm
"	2. reverse fork	
"	3. reverse idler shaft	Note roll pin which ensures shaft can only be fitted one way
"	4. thrust washer ← shaft	
"	5. gear ← shaft	
"	6. dowel bolt ← differential housing	15 Nm
"	7. dowel bolt ← differential housing	12 Nm
"	8. bolt ← differential housing	28 Nm
"	9. interlock assembly	Locates in machined groove at lower end of 1st/2nd selector shaft
"	10. shaft and fork assembly	If mainshaft is tight, tap upwards gently with soft hammer from differential housing end
"	11. bolt ← selector rod guide	30 Nm
"	12. selector rod guide ← differential housing	
"	13. detent cap bolt ← differential housing	22 Nm, collect ball and spring
"	14. selector rod ← differential housing	
Do not carry out further dismantling if component is removed for access only		
Measure	15. clearance	Shift arm to guide Standard 0.2 - 0.3 mm, 0.008 - 0.012 in Service limit 0.55 mm, 0.022 in Outside limit, measure width of groove in guide Standard 8.1 - 8.2 mm, 0.319 - 0.323 in Outside limit, renew guide
Remove	16. shaft ← interlock	
"	17. guide	
"	18. interlock	
"	19. shift arm assembly	
"	20. gaiter ← rod	
"	21. oil seal ← differential housing	Use 18G 1198 to fit new seal
Position	shift rod guide → interlock	
Measure	22. clearance	Selector rod guide to shift arm Standard 0.05 - 0.35 mm, 0.002 - 0.014 in Service limit 0.60 mm, 0.024 in Outside limit, measure width of groove in guide Standard 13.05 - 13.25 mm, 0.514 - 0.522 in Outside limit, renew guide Selector rod guide to interlock Standard 0.05 - 0.25 mm, 0.002 - 0.010 in Service limit 0.50 mm, 0.020 in Outside limit, measure outside dia. of interlock Standard 12.05 - 12.15 mm, 0.474 - 0.478 in Below limits, renew interlock
"	23. clearance	Selector fork assembly including detent balls and grooves. Balls and springs are retained by staking
Note	Assembled position	



XM0215 A

- Remove** 24. 1st/2nd fork ← shaft
Slide 25. shaft ← 5th fork
Remove 26. roll pin ← shaft
 " 27. reverse shift piece ← shaft
 " 28. 3rd/4th fork ← shaft
 " 29. 5th fork ← shaft
Measure 30. clearance

Use 5 mm, 0.2 in pin punch,

Fork to synchro sleeve, carry out this check on each fork and its sleeve,

Standard 0.45 - 0.65 mm, 0.018 - 0.026 in

Service limit 1.00 mm, 0.039 in

Outside limits, check fork thickness

Standard:

1st/2nd 8.90 - 9.00 mm, 0.350 - 0.354 in

3rd/4th 8.40 - 8.50 mm, 0.331 - 0.335 in

5th 5.40 - 5.50 mm, 0.213 - 0.217 in

Outside limits, renew fork

Fork OK, renew synchro sleeve and hub

Outside limits, renew fork

3rd/4th fork to shift arm guide

Standard 0.2 - 0.5 mm, 0.008 - 0.020 in

Service limit 0.8 mm, 0.032 in

Outside limits, renew guides

" 31. clearance

Clean components
Inspect components
Renew components

Any worn beyond limits

Continued . . .



MANUAL GEARBOX REPAIRS

Measure

32. clearance

Pin to L shaped groove

Standard 0.05 - 0.35 mm,
0.002 - 0.014 in

Service limit 0.5 mm, 0.020 in

Outside limit, measure width of L shaped
groove,

Standard 7.05 - 7.25 mm,
0.278 - 0.285 in

"

33. clearance

Reverse fork to gear

Standard 0.5 - 1.1 mm, 0.020 - 0.043
in

Service limit 1.8 mm, 0.071 in

Outside limit, measure width across prongs
of fork,

Standard 13.0 - 13.3 mm,
0.512 - 0.524 in







Outside limit, renew fork

Fit

"

gearbox case

gearbox ← vehicle



XM0217 A


Continued....



MANUAL GEARBOX REPAIRS

MAINSHAFT - RENEW

Action	Ref. Detail	Special Instructions
Remove	gearbox ← vehicle	
"	gearbox case	
"	selector forks and interlock assembly	
Lift	mainshaft and countershaft assembly ← differential housing	
Do not carry out further dismantling if component is removed for access only		
Lever	1. bearing ← mainshaft	Use two screwdrivers one each side ▲ CAUTION: If bearings or synchro assemblies are a tight fit, use a suitable puller to remove them
Note	assembled position	All gears and synchro assemblies
Remove	2. 5th synchro assembly ← mainshaft	Machined groove on hub faces 5th gear Large chamfer on sleeve faces away from 5th gear
"	3. 5th gear ← mainshaft	
"	4. needle roller bearing ← mainshaft	
"	5. spacer collar ← mainshaft	
"	6. needle roller bearing	
"	7. 4th gear ← mainshaft	
"	8. 3rd/4th synchro assembly ← mainshaft	Synchro hub will fit either way round. Both rings have three pairs teeth missing 120° apart
"	9. 3rd gear ← mainshaft	
"	10. needle roller bearing ← mainshaft	
"	11. bearing ← mainshaft	
Collect	12. belville washer ← mainshaft	PG2 gearbox only
Drift	13. oil seal ← differential housing	Use 18G 134, 18G 134 DH to fit new seal
Clean	components	
Inspect	gears	For wear or damage
"	shaft splines	For wear and blocked oilways
"	synchro rings	For wear or damage
"	cone surface	For wear
Assemble	synchro hub ← sleeve	Check for ease of movement. Repeat for each matched pair
Fit	synchro ring ← gear	Rotate ring until it locks 10° to 20° approx
Measure	clearance	Ring to gear Standard 0.85 - 1.1 mm, 0.033 - 0.043 in Service limit 0.4 mm, 0.016 in Outside limit, renew ring Repeat for each ring and gear As necessary
Renew	components	
"	all synchro springs	
Lubricate	components	With gearbox oil
Reassemble	components	Each synchro sleeve has three groups of long teeth 120° apart that must align with deep grooves on hub ▲ Note: Do not fit the differential housing bearing at this stage.
Position	assembled mainshaft → socket	Bearing inner race must contact rim of socket
Press	down on mainshaft assembly	



XM0216 A

Measure 14. clearance

CLEARANCE OUTSIDE LIMITS

Measure 3rd gear thickness

3rd gear to 2nd gear

Standard 0.06 – 0.21 mm, 0.002 – 0.008 in

Service limit 0.3 mm, 0.012 in

PG1¹ and PG2

Standard 35.42 – 35.47 mm, 1.394 – 1.396 in

Service limit 35.30 mm, 1.390 in

PG1²

Standard 32.42 – 32.47 mm, 1.276 – 1.278 in

Service limit 32.30 mm, 1.272 in

Gear outside limits, renew

Gear inside limits, renew 3rd gear synchro hub

" 15. clearance

4th gear to spacer collar

Standard 0.06 – 0.21 mm, 0.002 – 0.008 in

Service limit 0.3 mm, 0.012 in

CLEARANCE OUTSIDE LIMITS

Measure spacer collar thickness A

Standard 26.03 – 26.08 mm, 1.025 – 1.027 in

Service limit 26.01 mm, 1.024 in

Spacer outside limits, renew

SPACER INSIDE LIMITS

Measure 4th gear thickness

PG1¹ and PG2

Standard 33.45 – 33.47 mm, 1.317 – 1.318 in

Service limit 33.33 mm, 1.312 in

PG1²

Standard 30.92 – 30.97 mm, 1.217 – 1.219 in

Service limit 30.80 mm, 1.212 in

Continued....



MANUAL GEARBOX REPAIRS

Measure 16. clearance

CLEARANCE OUTSIDE LIMITS

Measure spacer collar thickness **B**

SPACER INSIDE LIMITS

Measure 5th gear thickness

5th gear to spacer collar

I Standard 0.06 – 0.21 mm,
0.002 – 0.008 in
Service limit 0.3 mm, 0.012 in

I Standard 26.03 – 26.08 mm,
1.025 – 1.027 in
Service limit 26.01 mm, 1.024 in
Spacer outside limits, renew

I PG1¹ and PG2

Standard 31.92 – 31.97 mm,
1.257 – 1.259 in
Service limit 31.80 mm, 1.252 in

I PG1²

Standard 30.47 – 30.52 mm,
1.199 – 1.201 in
Service limit 30.35 mm, 1.195 in
Gear outside limits, renew
Gear inside limits, renew 5th gear synchro
hub

Remove

"

"

Select

Fit

"

"

Reassemble

Fit

"

"


snap rings ← gearbox case
belville washer ← gearbox case
oil guide plate ← gearbox case
snap rings

belleville washer → mainshaft
bearing → mainshaft
17. protector sleeve → mainshaft
components
selector forks and interlock assembly
gearbox case
gearbox → vehicle


PG1 gearbox only

To give correct mainshaft end thrust
See **Adjustments**


I 18G 1269A










18G 284



18G 284-8



18G 284-7



XM0221

Continued . . .



MANUAL GEARBOX

REPAIRS

COUNTERSHAFT - RENEW

Action	Ref. Detail	Special Instructions
Remove	gearbox ← vehicle	
"	gearbox case	
"	selector forks and interlock assembly	
Lift	mainshaft and countershaft assembly ← differential housing	
<i>Do not carry out further dismantling if component is removed for access only</i>		
Lever	1. bearing ← mainshaft	Use two screwdrivers one each side ▲ CAUTION: If bearings or synchro assemblies are a tight fit, use a suitable puller to remove them
Remove	5th synchro hub ← mainshaft	PG2 gearbox only
Fit	2. spreader plate → shafts	18G 1473
Engage	two gears	To lock shafts
Release	lock washer ← nut	
Slacken	3. nut	L.H. thread 110 Nm
Engage	neutral	
Remove	spreader plate	18G 1473
Lift	mainshaft and countershaft assembly ← differential housing	
Note	assembled position	All gears and synchro assemblies
Remove	nut ← countershaft	L.H. thread
"	4. washer ← countershaft	Dished side towards bearing
"	5. bearing ← countershaft	Snap ring groove towards top
"	6. bearing ← countershaft	Wide face of bearing track faces upwards ▲ CAUTION: If bearings or synchro assemblies are tight fit, use a suitable puller to remove them
"		Large boss faces upwards
"	7. 5th gear ← countershaft	
"	8. 4th gear ← countershaft	
"	9. 3rd gear ← countershaft	
"	10. 2nd gear ← countershaft	
"	11. needle roller bearing ← countershaft	
"	12. collar ← countershaft	▲ Note: Lubrication groove on inner radius must be fitted towards synchro hub
"	13. 1st/2nd synchro assembly ← countershaft	▲ Note: Reverse gear teeth on sleeve must be fitted towards 1st gear, 2nd gear synchro ring has three pairs teeth missing 120° apart, locate in hub cut - away
"	14. 1st gear ← countershaft	
"	15. needle roller bearing ← countershaft	
"	16. thrust washer ← countershaft	Selective
"	17. bolts ← differential housing	2 off 12 Nm PG2 gearbox only
"	18. retainer plate ← differential housing	PG2 gearbox only
"	19. bearing ← differential housing	Insert 18G 284 - 8 and 18G 284 - 7 into bearing. Fit 18G 284 slide hammer and remove bearing.
"		▲ Note: Two oil holes must face upwards
"	20. oil guide plate ← differential housing	
Check	lubrication drilling	Must be clear
Clean	components	
Inspect	gears	For wear or damage
"	shaft splines	For wear and blocked oilways
"	synchro rings	For wear or damage
"	cone surface	For wear
Assemble	synchro hub ← sleeve	Check for ease of movement
Fit	synchro ring → gear	Rotate ring until it locks 10° to 20° approx.

MANUAL GEARBOX

REPAIRS





Measure ring → gear clearance

Standard 0.85 – 1.1 mm,
0.033 – 0.043 in
Repeat for remaining ring and gear
❑ Service limit 0.4 mm, 0.016 in
Outside limit, renew ring
As necessary

Renew components
"**"** all synchro springs
Lubricate components
Reassemble components

With gearbox oil
Synchro sleeve has three groups of long
teeth 120° apart that must align with deep
grooves on hub
By spigot end in soft jawed vice
L.H. thread ❑ 110 Nm. Slacken nut then
tighten again to ❑ 110 Nm

Secure assembled countershaft
Tighten new nut



Measure 21. clearance

Thrust washer to 1st gear
❑ Standard 0.03 – 0.08 mm,
0.001 – 0.003 in
Service limit 0.18 mm, 0.007 in
Select shims to bring end float within limits
❑ Shims available:
A 1.96 mm, 0.077 in
B 1.99 mm, 0.078 in
C 2.02 mm, 0.080 in
D 2.05 mm, 0.081 in
E 2.08 mm, 0.082 in

XM0220

Continued . . .



MANUAL GEARBOX

REPAIRS

Measure

22. clearance

2nd gear to 3rd gear

PG1¹ and PG2

Standard 0.03 – 0.08 mm, 0.001 – 0.003 in

PG1²

Standard 0.03 – 0.10 mm, 0.001 – 0.004 in

Select collar to bring end float within limits

Collars available:

A 29.03 – 29.05 mm, 1.143 – 1.144 in

B 28.98 – 29.00 mm, 1.141 – 1.142 in

Fit

oil guide plate → differential housing

"

bearing → differential housing

"

retaining plate → differential housing

"

bolts → differential housing

Fit bearing with oil holes upwards,

use 18G 1353

PG2 gearbox only:

12 Nm, use centre punch to stake bolt heads into groove in plate

Reassemble

components

Fit

components

"


selector forks and interlock assembly

"

gearbox case

"

gearbox → vehicle



XM0225



Continued . . .



MANUAL GEARBOX REPAIRS

DIFFERENTIAL - PG1 GEARBOX - OVERHAUL

Action	Ref. Detail	Special Instructions
Remove	gearbox ← vehicle	
"	gearbox case	
"	selector forks and interlock assembly	
Lift	mainshaft and countershaft assembly ← differential housing	
"	differential ← differential housing	
Remove	1. bearings ← differential	Use 18G 2, 18G 2-3 and 18G 1397 ▲ Note: Speedometer pinion not serviced separately 5.0 mm. 0.2 in dia. punch
Insert	2. pin punch → differential	
Drift	3. roll pin ← pinion pin	
Remove	4. pinion pin ← differential	
"	5. planet pinions ← differential	2 off
Collect	6. thrust washers	2 off, selective
Remove	7. sun gears ← differential	2 off
Collect	8. thrust washers	2 off non selective
Mark	final drive gear → differential	For reassembly
Remove	9. bolts ← differential	10 off
Separate	10. final drive gear ← differential	
Remove	11. differential oil seals	
Collect	12. circlip ← gearbox case	
Clean	components	
Inspect	components	For wear or damage
Lubricate	components	Use molybdenum disulphide grease
Fit	final drive gear ← differential	Chamfer on inner radius towards differential
Tighten	bolts → differential	110 Nm
Reassemble	differential	Use 18G 1359/1 to press on bearings, do not fit roll pin



XM0224

Position
Fit
Position
Measure

13. differential → V blocks
14. drive shafts ← differential
15. dial gauge → differential backlash

Reassemble
Fit
"
"
Seat

components
mainshaft and countershaft
selector forks and interlock assembly
gearbox case
differential

Measure

16. clearance

Fit

circlip → gearbox case
"
differential oil seal
"
gearbox → vehicle

To align sun gears

As illustrated

■ Backlash = 0.05 – 0.15 mm,
0.002 – 0.006 in

OK, secure pinion pin with new roll pin

Not OK, dismantle differential, select pinion thrust washers to give correct backlash

▲ CAUTION: Washers must be equal thickness

■ Thrust washers available

0.70 – 0.05 mm, 0.028 – 0.041 in

0.70 mm (0.028 in) – 1.05 mm (0.041 in)

in steps of 0.05 mm, 0.002 in

If correct backlash cannot be obtained, renew components in following order rechecking backlash at each stage. Planet pinions, sun gears, differential housing

Lightly drive towards differential housing to seat circlip, then drive towards gearbox case until it is seated

Circlip to bearing outer face

■ clearance = 0.15 mm, 0.006 in maximum

Outside limits, select alternative circlip

■ circlips available

PG1¹

2.45 – 2.95 mm, 0.096 – 0.116 in

PG1²

2.50 – 3.0 mm, 0.098 – 0.118 in
in steps of 0.10 mm, 0.004 in


Circlip can be removed and refitted through oil seal aperture

Use **■** 18G 134, **■** 18G 134-12



MANUAL GEARBOX

REPAIRS




DIFFERENTIAL - PG2 GEARBOX - OVERHAUL

Action	Ref. Detail	Special Instructions
Remove	gearbox ← vehicle	
"	gearbox case	
"	selector forks and interlock assembly	



Lift	mainshaft and countershaft assembly ← differential housing
"	differential ← differential housing
Remove	1. bearings ← differential
Insert	2. pin punch → differential
Drift	3. roll pin ← pinion pin
Remove	4. pinion pin ← differential
"	5. planet pinions ← differential
Collect	6. thrust washers
Remove	7. sun gears ← differential
Collect	8. thrust washers
Mark	final drive gear → differential
Remove	9. bolts ← differential
Separate	10. final drive gear ← differential
Remove	11. differential oil seals
Drift	12. bearing outer track ← differential housing
"	13. bearing outer track ← gearbox case
Collect	14. shim ← gearbox case
Clean	components
Inspect	components
Lubricate	components
Fit	final drive gear → differential
Tighten	bolts → differential
Reassemble	differential
Position	15. differential → V blocks
Fit	16. drive shafts → differential
Position	17. dial gauge → differential
Measure	backlash



XM0226

Check	differential bearing pre-load
Reassemble	components
Fit	mainshaft and countershaft
"	selector forks and interlock assembly
"	gearbox case
"	gearbox → vehicle

Use 18G 2, 18G 2-3 and 18G 1397

▲ Note: Speedometer pinion not serviced separately

5.0 mm, 0.2 in dia. punch



2 off

2 off, selective

2 off

2 off non selective

For reassembly

10 off

18G 1526 to fit new seals

Outer tracks can be removed by immersing housings in hot water

For wear or damage

Use molybdenum disulphide grease

Chamfer on inner radius towards differential

123 Nm

Use 18G 1396 to press on bearings, large bearing adjacent to speedometer gear. Do not fit roll pin

To align sun gears

As illustrated

Backlash = 0.05 - 0.15 mm, 0.002 - 0.006 in

OK, secure pinion pin with new roll pin

Not OK, dismantle differential, select pinion thrust washers to give correct backlash

▲ CAUTION: Washers must be equal thickness

Thrust washers available 0.70 mm (0.028 in) - 1.05 mm (0.041 in) in steps of 0.05 mm, 0.002 in


If correct backlash cannot be obtained, renew components in following order rechecking backlash at each stage. Planet pinions, sun gears, differential housing

See **Adjustments**



MANUAL GEARBOX

REPAIRS



NEUTRAL AND REVERSE LIGHT SWITCHES - RENEW

Action	Ref. Detail	Special Instructions
Raise	front of vehicle	
Disconnect	1. multiplug ← harness	⚠ WARNING: Support on safety stands
Unscrew	2. neutral switch ← gearbox	2 off as required
"	3. reverse switch ← gearbox	25 Nm
Remove	4. sealing washer ← switch	25 Nm
Clean	sealing faces	
Reassemble	components	
Top - up	gearbox oil level	See Adjustments